Operating Manual

USER'S INSTRUCTIONS

High Resolution DNR Day/Night Color Camera

ISO9001 / ISO14001 / ROHS

Safety Instructions

● Precautions for use

Please read this manual enough before using this camera to obtain the skill of correct operation.

● Warranty

- This manual is including Warranty Card at last page. This warranty card is available within One(1) year from the 1st date when you purchased this unit and keep this warranty card well for A/S. The A/S cost would be free of charge except only user's fault in warranty year.
- Keep the camera box well and it could be used when it need to have after Service.

● Cautions when using

- Do not open the camera body and touch to prevent electric shock.
- Do not insert other object into camera body to prevent hazards of fire and electric shock.
- Do not touch with wet hands to prevent electric shock.
- Do not pull out by taking power cord when plug out from the outlet.
- Must pull out by taking plug socket.
- If the camera has burning smells, please plug out and ask to shop where you bought It or the nearest A/S center.

● Cautions when Install

- Plug on after installation of all device.
- Do not install the camera face to strong light directly.
- Do not install or use the camera in places where the humidity is high.
- Do not install near the cooling device or heating device.
- Do not install the camera where is high humidity or heavy dust.
- Do not install the camera to the place where it has physical shocks.
- Do not expose the camera to rain or moisture.
- This products must use DC adaptor for power.

CONTENTS

- General Features ---------- 3
- Operating Key Button ---------- 5
- Camera Menu Set Up ---------- 6
  1. LENS (Option) ---------- 8
  2. Shutter Speed ---------- 9
  3. WHITE BALANCE ---------- 10
  4. BACKLIGHT (BLC) ---------- 11
  5. AGC Function (Auto Gain Control) ---------- 12
  6. DNR ---------- 13
  7. SENS-UP ---------- 14
  8. SPECIAL ---------- 15
- SPECIFICATIONS ---------- 2

General Features

- **DNR DSP Chip**
  - DNR is superior DSP chipset enhanced various and powerful function of high resolution, Day & Night,Removing camera noise and sense up, as well. It is the highest and advanced technology that is unified Up-most necessary functions by one DSP chipset enhanced powerful surveillance functions.
- **560TV Lines**
  - Unification of DNR Technology and Sony Super HAD CCD image sensor provides Clear & Superior High resolution of 560 TV lines.
- **Day & Night**
  - Up to the lighting conditions, the video automatically switching to color mode in bright zone and Monochrome mode in dark zone making to achieve safe and perfect 24 hours surveillance.
- **Electronic IRIS**
  - The electronic IRIS function enables continuous automatic control of the shutter between 1/60(1/50) ~ 1/120,000 seconds.
- **Illumination**
  - Ultra Advanced DNR technology enhanced incredibly minimum illumination of amazing 0.0002 Lux With capture of good image under the extremely low light conditions.
- **DNR(Digital Noise Reduction)**
  - DNR technology solved the trouble of ghost figures, it displaying clearer, superior High resolution even in extremely low light circumstance.
- **Disk Saving Effects**
  - Up-most and advanced DNR technology camera picture quality has a disk saving effects due to Image sizes are smaller than standard CCTV camera image.
- ***Controlled by OSD Menu***
  - The camera can be controlled by selecting the menu text displayed on the monitor screen

OSD Control Button

1. Type A, Type B, Type C of OSD button could be used when it needs to OSD control.
2. Type D is extra Option (wired Remote controller)

Type A



Type.B



Type C



Type D (Option)

How to Set Up the camera menu

● Setup Menu

SETUP				
LENS(Option)	● MANUAL	● DC/VIDEO		
SHUTTER(Shutter Speed control)	● ESC	● MANUAL	● FLK	
WHITE BALANCE	● ATW	● AWC	● MANUAL	
BACKLIGHT(BLC)	● OFF	● LOW	● MIDDLE	● HIGH
AGC(Auto gain control)	● OFF	● LOW	● MIDDLE	● HIGH
DNR(Digital Noise reduction)	● OFF	● LOW	● MIDDLE	● HIGH
SENS-UP	● OFF	● AUTO		
SPECIAL	● CAMERA ID	● COLOR	● COLOR GAIN	
	● SYNC	● MOTION DET	● PRIVACY	
	● MIRROR	● SHARPNESS	● RESET	● RETURN
EXIT				

● Menu Set up

Menu could be adjusted by the OSD button of the camera.

1. Press the setup button.
   - Setup menu will display on the monitor.



2. Move and Select the function what you want to control by the button.
   - Move the arrow indicator UP or Down to indicate onto desired feature by pressing the UP or Down button.



3. Menu Set Up will change by Left or Right Button
   - Available value or Status will be displayed by pressing the Left or Right button. Please press the button until desired features appears.
4. After complete the adjustment, move the arrow indicator to "EXIT" and press the "SET" button to Exit.

CAUTION

- ▶ Moving available to submenu by moving the ↵ arrow to desired feature.
- ▶ Access are not available to submenu on the mode of "- - - -".

LENS (Option)

It's function of control the picture brightness.

1. Move to arrow indicator to "LENS" by pressing of UP or Down button on the Set Up menu screen.
2. Select the desired lens type by pressing of Left or Right button.



→DC/VIDEO : DC Auto IRIS lens

CAUTION

▶ Available to control the brightness when selected DC. Brightness control range will be 1 ~ 70.



→MANUAL : Manual Lens

3. Press the SETUP button to return previous menu.

Shutter Speed Control

It's a function of selecting the Automatic shutter speed control or Manual shutter speed control.

1. On the Set Up menu screen, move the arrow indicator to shutter by using of UP or Down button.
2. Select desired shutter mode by pressing of Left or Right Button.
   - FLK : Select "FLK" mode when it has flickering by unmatched of electric lights and radio waves.
   - ESC : Available automatic shutter speed control. Brightness could be automatically controlled when Selected "ESC" mode.
   - MANUAL : Shutter speed could be controlled by manually.



3. Manual shutter speed could be controlled when select .
   - Manual shutter speed could be controlled from 1/60 to 1/120,000sec.
4. Press the Set Up button to exit after completed the set up menu.

CAUTION

- ▶ Lens Shutter speed will be fixed to 1/60sec. when selected DC/VIDEO lens.
- ▶ Do not make the camera exposed fluorescent lamp directly. It should be caused of unstable image quality in the internal synchronization mode.
- ▶ In case of Shutter menu selected to Manual mode, SENS UP does no work. Please control the menu.

WHITE BALANCE

Use the White Balance function when need to color control on the screen.

1. Move the arrow indicator to 'WHITE BAL' by pressing of SET button on the SETUP Menu screen.
2. Select desired mode by using of Left or Right button.



※ Select in below 3 functions up to user's purpose.

- ATW : It is suitable in the color temperature ranges from 1,800°K to 10,500°K
- AWC : In order to obtain the best result, press the Set button while the camera focuses onto White paper. If the environment and/or lights source has changed, it could be readjusted the white balance.
- MANUAL : Available to fine adjustment in case of selected to Manual mode. After adjustment of ATW or AWC, select the manual mode and press the SETUP button to increase or decrease the value of R-Gain(RED) and B-Gain(Blue) while watching the color of image. Press the SET button when obtained the desired best color.

CAUTION

Proper White Balance may not be worked under the following conditions. In that case, Select the AWC mode

- ▶ When the scene of object has most high color temperature.(Ex:Blue Sky, Sunset)
- ▶ When the scene of object is so dim.
- ▶ When install the camera in place of the changing illumination and/or faces directly to Fluorescent lights.

Backlight (BLC)

This camera provide intelligent light level control to overcome the severe Backlight condition.

1. Move the arrow indicator to 'BACKLIGHT' by pressing of UP or Down button on the SETUP Menu screen.
2. Select the desired mode by pressing of Left or Right button.



- HIGH : Gain could be increased max. from 6dB to 34dB.
- MIDDLE : Gain could be increased max. from 6dB to 30dB.
- LOW : Gain could be increased max. from 6dB to 18dB.
- OFF : BACKLIGHT function will not operated.

BACKLIGHT ON

BACKLIGHT OFF

AGC (AUTO GAIN CONTROL)

1. Move the arrow indicator to 'AGC' by pressing of UP or Down button on the SETUP Menu screen.
2. Select the desired mode by pressing of Left or Right button. AGC is for bright image. Higher gain level makes brighter screen but increases the noise
   - HIGH : Gain could be increased from 6dB to 34dB max.
   - MIDDLE : Gain could be increased from 6dB to 30dB max.
   - LOW : Gain could be increased from 6dB to 18dB max.
   - OFF : Gain will be fixed at 6dB.



3. Press the SETUP button. The BRIGHTNESS could be adjusted from 1 to 70 max.



4. Press the SETUP button when completed the menu set up.

DNR (Digital Noise Reduction)

DNR is to reduce the digital noise on the screen.

1. Move the arrow indicator to 'DNR' by pressing of UP or Down button on the SETUP Menu screen.
2. Select the desired mode by pressing of Left or Right button.
   - HIGH : High reduction of noise but ghost effect will be appear.
   - MIDDLE : Middle reduction of noise but most effective with less ghost effect.
   - LOW : Low reduction of noise without ghost effect.
   - OFF : Deactivation.



SENS-UP

It could be always displayed clear image with this function even under low lighting level or night time.

1. Move the arrow indicator to 'SENS-UP' by pressing of UP or Down button on the SETUP Menu screen.
2. Select the desired mode by pressing of Left or Right button.
   - AUTO : Auto mode status
   - OFF : Deactivation

CAUTION

- ▶ When AGC OFF, SENS-UP does not working.
- ▶ When SHUTTER selected to MANUAL, SENS-UP does not working.



3. Press the SETUP button when completed the menu set up.

CAUTION

- ▶ If press the SETUP button, it could be controlled maximum magnifications. (Adjusted to 12 Step)
  - Expanding magnifications, screens brighter after image sensitivity but increasing the noise on the screen.
  - When SENS-UP activated, increasing magnification makes noise, spots and whitish.(It is not out of order)

SPECIAL

1. Move the arrow indicator to 'SPECIAL' by pressing of UP or Down button on the SETUP Menu screen.
2. Select the desired mode by pressing of Left or Right button.



▶ **CAMERA ID : If inputted ID, Camera ID will be displayed onto the screen.**

1) Move the arrow indicator to 'Camera ID' by pressing of UP or Down button on the SETUP Menu screen
2) Set "ON" by using of Left or Right button.

CAUTION

- ▶ When Camera ID is set to "OFF", The Camera ID will not displayed onto the monitor.

3) Press the SETUP button..

4) ID could be entered up to 15 characters.
① Move the cursor to character enter location by using of Left or Right button.

② Select the desired character in A, B~Y, Z, a, b~y, z, 0, 1~8, 9 by using of Up, Down, Left And Right button.
③ Set the desired character by pressing of SETUP button.
- The cursor will move to next position after character select by pressing SETUP button.

④ Repeat above steps until created the desired full name.

CAUTION

▶ **In Case of Wrong Camera ID Input·····**
Move the cursor to "CLR" and press the SETUP button from right to left to erase the characters.
And repeat above steps to correct the characters again.

5) Select the position at camera ID should be located on the screen.
① Move the cursor to"POS" and press the SET button.

② Created Camera name will be displayed.



③ Select the position by using of the 4-Directional button, then press the SET Button to confirm the position.

6) Move the cursor to "END" and press the SET button after completed the above processing.

▶ **COLOR (Electronic DAY & NIGHT)**
- AUTO : Electronically sensing Day & Night.
- ON : Fixed only color mode.

CAUTION

▶ Color mode could not available when AGC OFF.

▶ COLOR GAIN

Available to increase or decrease the Chroma level but BURST signal will not change.

- It could be selected desired *level from 1 to 100.*



CAUTION

▶ COLOR could be adjusted by control the color gain.

▶ SYNC

The line lock synchronization is used in only areas of 60Hz (NTSC) and 50Hz(PAL).

- INT : Internal Synchronization
- L/L : Line Lock mode

* Press the SETUP button.

* It could be adjusted to desired phase from 0 to 359.



CAUTION

▶ In DC 12V, the SYNC menu sets" INT" mode.

▶ MOTION DETECTION (MD)

Whenever the camera detects motion of object displaying "Motion Detected" with the counting up of number on the Screen.

* Press the SETUP button.
- OFF : Deactivation
- ON : Selected AREA will be detected by MOTION sensing.

* In AREA SEL, it could be selected desired detection area by each cameras.

* Set ON selected AREA state (Activated).

* *Move the arrow indicator to adjust* sharpness of detection Area by using of TOP, BOTTOM, LEFT, RIGHT.



Press the SETUP button to save the selected data.

CAUTION

▶ MD will be displayed on the screen but there is not OUTPUT signal.

It masking the area which is desired areas to mask.
- OFF : Deactivated
- ON : PRIVACY mode activated

* Press the SETUP button.

* In AREA SEL, it could be selected desired masking area by each cameras.

* Set ON selected AREA state (Activated).

* *Move the arrow indicator to* adjust sharpness of Privacy Area by using of TOP, BOTTOM, LEFT, RIGHT. Privacy area tone could be adjusted by using of Area tone.



▶ **MIRROR**
- ON : Activated Reverse turning Right to Left.
- OFF : Deactivated.

MIRROR OFF

MIRROR ON

▶ **SHARPNESS**

To make image clear, Sharpness level needs to up. The level could be controlled to get proper image. When level is too much higher it would be caused of unnatural image with the noise.
* Press the SETUP button.
* It could be controlled desired LEVEL from 1 to 31.



▶ **RESET**

Factory default set.

▶ **RETURN**

Save the setting of SPECIAL function and then move to SETUP menu.

EXIT

Save the all of setting menu and exit.

SPECFICATIONS

Image Pick-Up Device	1/3" SONY SUPER HAD CCD
TV Scanning	NTSC,PAL
Total Pixels	NTSC=811(H)*508(V)/PAL=795(H)*596(V)
Effective Pixels	NTSC=768(H)*494(V)/PAL=752(H)*582(V)
Scanning Frequency	NTSC=15.734KHz(H)/59.94Hz(V)/PAL=15.625KHz(H)/50.00Hz(v)
Scanning System	2:1 Interlace
Synchronization	Internal/Line Lock
Resolution	560TV Lines
Minimum Illumination	0.002LUX(Sens-Up*128x)
S/N Ratio	More than 50dB
White Balance	ATW/AWC/MANUAL(1800 K~10,500 K)
Gamma Characteristic	Internal/Line Lock selectable
Video output	CVBS : 1.0Vp-p 75ohm
Electronic Shutter Speed	NTSC=Auto/Manual(1/60sec~1/120,000sec)/PAL=Auto/Manual(1/50sec~1/120,000sec
OSD	Built-In
BLC	Low, Middle, High, Off Selectable
AGC	Low, Middle, High, Off Selectable
DNR	Low, Middle, High, Off Selectable
Day&Night(Color)	On/Auto Selectabl(Electrical)
Sharpness	On/Off(Level Adjustable)
Privacy	On/Off(4 Programmable Zone)
Power Supply	DC12V(AC 24V Option)
Operational Temp	-10 ~ +50Deg C. RH 95% Max
Storage Temp	-20 ~ +60Deg C. RH 95% Max

Memo

USER'S MANUAL

Memo